



Potenza Power	Grado di Protezione International protection	Corrente Alimentazione Current Supply
16W	IP40	220 Vac

IT Istruzioni di montaggio e collegamento

EN Assembly and connection instructions

**ATTENZIONE: NON COLLEGARE DIRETTAMENTE ALLA TENSIONE ELETTRICA DI RETE.**


Per collegare l'apparecchio alla tensione elettrica di rete è indispensabile un alimentatore con uscita in tensione costante. La potenza in Watt erogata dall'alimentatore deve essere pari o superiore a quella richiesta da uno o più apparecchi. Evitare usi impropri e manomissioni dei meccanismi del prodotto.




**CAUTION: DO NOT CONNECT DIRECTLY TO LINE VOLTAGE.**

A power supply with a constant voltage output is necessary to connect the appliance to mains power. The watts of the power supply shall be equal to or greater than the power required by one or more appliances. Avoid improper use and tampering with the product's mechanisms.


01




02




03




04




05




06




07




08




08.b




09



10



11



Link sito web | Website link

Questo dispositivo è munito di lampade LED integrate. Le lampade di questo dispositivo non sono sostituibili.  
This device has built-in LED lamps. The lamps in this device are not replaceable.